



IMPORTANT INFORMATION AND RESTRICTIONS:

1. **When using several DZ209/5 or DZ209/10 diode boards, you must connect the terminals marked '8' on all the DZ209 diode boards together.**
2. **Do not connect the diode boards to terminal 'Z' and 'ZW' on the PK292A amplifier. Only one of these terminals may be used, depending upon the tone sound desired at the apt. handsets.**

INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. To install the DZ209 diode boards, simply remove the paper from the self-stick tabs and install into the back box in a convenient, dry location. Make sure none of the electrical contacts are being shorted.
2. The microphone in the entrance panel MUST BE the MI004 series microphone.
3. Make sure you connect the side of the DZ209 board labelled 'HT' to the selective terminals marked 'A' on the TA292A handsets.
4. See the TA292A/PK292A wiring diagram for the balance of the wiring connections required.
5. All wiring is #22 AWG, unless otherwise noted.
6. Observe all local and national electrical codes.
7. All terminals connections shown may not be in the order that they appear on the equipment.



42 Central Drive, Farmingdale NY 11735-1202
 (631) 777-5500 Fax: (631) 777-5599
TOLL-FREE Technical Line 1-800-666-4800
 Email: info@alpha-comm.com

DZ209 DIODE BOARD WITH PK292A INSTALLATION INSTRUCTIONS

For use with the TA292A (2-Wire) Apartment
 Intercom Handset Station and PK292A Amplifier