


**INSTALLATION GUIDELINES and GENERAL INFORMATION:**

1. See the specific system wiring diagram for the balance of the wiring connections required.
2. All wiring is #22 AWG, unless otherwise noted.
3. Observe all local electrical codes.

 <p>42 Central Drive, Farmingdale NY 11735-1202          (631) 777-5500 Fax: (631) 777-5599  <b>TOLL-FREE Technical Line 1-800-666-4800</b>  <i>Email: info@alpha-comm.com</i></p>	<p style="text-align: center;"><b>TYPICAL LOUD-SPEAKING LOBBY          PANEL WIRING INSTRUCTIONS</b></p> <p>For use only with Open-Voice (Loud-Speaking)          type Apartment Intercom Stations</p>
---	--