



INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. See the specific system wiring diagram for the balance of the wiring connections required.
2. All wiring is #22 AWG, unless otherwise noted.
3. Observe all local electrical codes.



42 Central Drive, Farmingdale NY 11735-1202
(631) 777-5500 Fax: (631) 777-5599
TOLL-FREE Technical Line 1-800-666-4800
Email: info@alphacommunications.com

TYPICAL LOUD-SPEAKING LOBBY PANEL WIRING INSTRUCTIONS

For use only with Open-Voice (Loud-Speaking)
type Apartment Intercom Stations