

```

+-----+
!
! NOTES-
!
! 1. ALL WIRING MUST BE MINIMUM #22AWG SHIELDED UNLESS SHOWN OTHERWISE.
!
! 2. IT IS RECOMMENDED THAT THE NH908A POWER SUPPLY BE INSTALLED INTO
!   A LOCKED CABINET, FOR SECURITY PURPOSES.
!
! 3. MAKE SURE TO USE ONLY THE 16VAC OUTPUT FROM THE SS106 TRANSFORMER.
!
! 4. MAKE SURE TO OBSERVE ALL LOCAL ELECTRICAL CODES.
!
! 5. ANY TERMINALS SHOWN ON THE NH908A WITHOUT CONNECTIONS, ARE NOT USED.
!
! 6. TERMINALS SHOWN MAY NOT BE IN THE SAME ORDER AS THEY APPEAR ON THE
!   ACTUAL EQUIPMENT.
!
!
!   NH908A OR
!   NH908LZ
!   POWER SUPPLY
!   +-----+
!   !           !
!   ! 16V-----> CONNECT THESE (2) TERMINALS
!   !           !           TO THE 16VAC OUTPUT FROM THE
!   ! 16V-----> SS106 TRANSFORMER (#18AWG MINIMUM)
!   !           !
!   !           !
!   !           !
!   !           !           TW202           TW202
!   !           !           VISITOR           VISITOR
!   !           !           HANDSET           HANDSET
!   !           !           #1                 #2
!   !           !           +----+           +----+
!   !           !           !  !           !  !
!   !   M-----RED-----M-----M
!   !           !           !  !           !  !
!   !   O-----BLUE-----O-----O
!   !           !           !  !           !  !
!   !   T-----WHITE-----T-----T
!   !           !           !  !           !  !
!   !           !           +----+           +----+
!
!   NOTE: ABOVE WIRE COLORS ARE ONLY USED ON MODIFIED TW202 UNITS
!         WITH PLUG-IN CONNECTORS. IF CONNECTORS ARE NOT USED, YOU
!         MAY USE WHATEVER COLORS YOU DESIRE.
!
!
!

```

```

+-----+
!   ALPHA COMMUNICATIONS   ! TYPICAL WIRING DIAGRAM FOR THE   ! Diagram#
!   42 CENTRAL DRIVE       ! TW202 SERIES 2-STATION VISITOR'S ! WDTW202
!   FARMINGDALE NY 11735  ! INTERCOM SYSTEM(S) WITH THE NH908A !=====
!   631-777-5500         ! OR NH908LZ AMPLIFIER/POWER SUPPLY ! 05/17/02
+-----+

```